



**the hallicrafters co.**

MANUFACTURERS OF ELECTRONIC EQUIPMENT, CHICAGO 24, U. S. A.



092-104533

Figure 1. Hallicrafters Model S-108.

## SECTION I GENERAL DESCRIPTION

### 1-1. INTRODUCTION.

Your new Hallicrafters Model S-108 is a precision built, highly sensitive, communications receiver providing complete coverage in the frequency range of 538 kilocycles to 34 megacycles. Eight tubes, including one rectifier, are employed in the latest superheterodyne circuit and provision is made for the reception of AM or CW signals over the entire tuning range.

For ease and flexibility of operation, two tuning dials are provided. The circular dial provides the general frequency coverage, while the slide rule type dial (the bandspread dial) is specifically calibrated for the 80, 40, 20, 15 and 10 meter bands.

For increased selectivity, an automatic noise limiter circuit can be switched into operation to provide a means of receiving many signals that would be lost in background noise with ordinary receiving equipment.

Other special features include full range TONE

control, SENSITIVITY control with provision for the optional use of AVC, a STANDBY-RECEIVE switch that permits silencing the receiver while maintaining it ready for instant use, without waiting for the tubes to warm up, and a headphone (PHONES) jack mounted on the front panel. Also included is a built-in Alnico V permanent magnet speaker for assured lifelike reproduction.

### IMPORTANT

Careful attention should be directed to the "INSTALLATION" and "OPERATION" instructions. They have been provided to insure the satisfaction you have a right to expect from any Hallicrafters "Precision Built" product. Your receiver has an unusually high degree of sensitivity necessary to receive weak and distant stations. Careless operation of a high sensitivity receiver may result in excess noise or background hiss. These undesirable effects can be held to a minimum by careful adjustment of the SENSITIVITY, TUNING, and TONE controls as well as the proper selection and arrangement of the antenna.

## SECTION II INSTALLATION

### 2-1. UNPACKING.

After unpacking the receiver, examine it closely for damage which may have occurred in transit. Should any sign of damage be apparent, file a claim immediately with the carrier stating the extent of damage. Carefully check all shipping labels and tags for instructions before removing or destroying them.

### 2-2. LOCATION.

The receiver is equipped with rubber mounting feet for table or shelf mounting. When locating the receiver, avoid excessively warm locations such as those near radiators and heating vents. Allow at least one inch of clearance between the back of the receiver and the wall for proper ventilation.

### 2-3. POWER SOURCE.

The S-108 receiver is designed to operate from a 105-125 volt, 50-60 cycle AC power source. Power consumption is 75 watts.

#### IMPORTANT

If in doubt about your power source, contact your local power company prior to inserting the power cord into an AC power outlet. Plugging the power cord into the wrong power source may cause extensive damage to the unit, requiring costly repairs.

### 2-4. ANTENNAS.

The RF input of the receiver is designed for operation from either a single-wire antenna, or a half-wave doublet or other tuned antenna with transmission line impedances from 52 to 600 ohms. Antenna connections are made to a three-terminal strip at the rear of the receiver marked "A1", "A2", and "G".

#### 2-4-1. SINGLE WIRE ANTENNA.

The simplest antenna and one which will provide satisfactory results throughout the entire tuning range is a conventional single-wire antenna. In most localities, good results can be obtained with just the 15-




Figure 2. Single Wire Antenna.

foot length of antenna wire supplied with the receiver. Simply attach one end of this wire to terminal "A1", connect the jumper link between terminals "A2" and "G", and then run the wire about the room in any convenient manner. (See Fig. 2.) If the receiver is operated in a steel constructed building or where receiving conditions are exceptionally poor, an outside antenna should be erected as high as possible and kept free from surrounding objects. In some locations, reception may be improved by connecting a ground wire (ordinary copper wire) from terminal "G" to a cold water pipe or outside ground rod. While the use of an outside ground rod installed in accordance with Insurance Underwriter's Laboratories requirements is adequate protection against lightning, we strongly recommend an additional connection to the nearest cold water pipe to eliminate any shock hazard.

#### 2-4-2. HALF-WAVE DOUBLET ANTENNA.

For top performance, a half-wave doublet or other type of antenna employing a 52 to 600-ohm transmission line is recommended. A typical doublet antenna installation is shown in Fig. 3. The doublet antenna should be cut to the proper length for the most used frequency or band of frequencies. The overall length in feet of a doublet antenna is determined by the following formula:

$$\text{Length in feet} = \frac{468}{\text{Frequency in megacycles}}$$

When erecting the doublet antenna, it should be remembered that it displays directional properties broadside to its length and should be so oriented with respect to a desired station for maximum signal pick-up.

The doublet antenna may be fed with either a balanced or unbalanced transmission line. When a balanced transmission line such as "twin-lead" or a twisted pair is used, the transmission line connects to terminals "A1" and "A2", and the jumper link between terminals "A2" and "G" is disconnected. When using an unbalanced transmission line such as coaxial cable, the inner conductor connects to terminal "A1", the outer braid connects to terminal "A2", and the jumper




Figure 3. Doublet Antenna Using  
Twin-Lead Transmission Line.




Figure 4. Receiver Operating Controls.

link connects between terminals "A2" and "G". A ground wire may improve reception when using an unbalanced transmission line.

The doublet antenna provides optimum performance only at the frequency for which it is cut. Therefore, it may be desirable for reception on frequencies remote from the antenna frequency to utilize the antenna as a single wire type. This is accomplished by connecting the two transmission line leads together and connecting them to terminal "A1". The jumper link in this case should be connected between terminals "A2" and "G".

In an installation where the receiver is used in conjunction with a transmitter, it may be advantageous to use the same antenna for receiving as for transmitting. This is especially true when a directive antenna is used since the directive effects and power gain of the transmitting antenna are the same for receiving as for transmitting. Switching of the antenna from the

transmitter to the receiver may be accomplished with a double-pole, double-throw antenna changeover relay or knife switch connected in the antenna leads.

For further information regarding antennas, refer to the "Radio Amateur's Handbook" or the "A. R. R. L. Antenna Book", both published by the American Radio Relay League, West Hartford, Conn., U. S. A.

## 2-5. HEADPHONES

The headphone jack, marked "PHONES", is located on the front panel of the receiver and is wired so that the speaker is automatically disabled when the headphones are plugged in. The headphone output impedance is not critical and any commercial headphones may be used, including crystal types, as no direct current flows in the headphone circuit. For maximum headphone output, the use of low-impedance magnetic phones (50 to 1,000 ohms) is recommended.

# SECTION III OPERATION

## 3-1. GENERAL.

Each control of your receiver performs a definite function which contributes to its outstanding reception capabilities. Full appreciation of the receiver is to be expected only after you have become familiar with each of the controls and the effect each control has on the performance of the receiver.

As a special convenience for those not yet familiar with the full advantages of the various controls, the control settings commonly used for broadcast reception are marked with a dot.

## 3-2. SENSITIVITY CONTROL.

The SENSITIVITY control is used in combination with the VOLUME control to regulate the level of receiver output.

The setting of the SENSITIVITY control determines the ability of the receiver to pick up weak or distant stations. This control is normally set at the extreme clockwise position, when receiving AM signals, and at some other position when receiving CW signals. Maximum sensitivity may be used while tuning across the frequency range, but if the station se-

lected has too strong a signal, excessive background hiss or distortion may be present. If this undesirable effect is produced, it can be greatly reduced by turning the SENSITIVITY control in the counterclockwise direction to a slightly lower setting. If, after reducing the sensitivity, more volume is needed, advance the VOLUME control. When receiving CW signals, a setting of the SENSITIVITY control that is too high will be evidenced by "thumping" (overloading).

### 3-3. BAND SELECTOR CONTROL.

The BAND SELECTOR control should be set for the band you wish to tune. The four positions of this control correspond to the band numbers at either side of the main tuning dial.

### 3-4. AM-CW SWITCH.

Set this switch at "AM" to listen to voice broadcasts. Set it at "CW" only, if you wish to hear code signals.

### 3-5. AVC SWITCH.

The AVC switch, when set at "ON", places the automatic volume control circuit in operation to maintain a uniform volume level, regardless of variations in signal strength at the antenna. For AM reception, this switch should normally be set at "ON". For CW reception, this switch should be set at "OFF".

### 3-6. NOISE LIMITER SWITCH.

This switch should normally be set at "OFF". If severe electrical disturbances, ignition noise, or other types of pulse-type noise interfere with reception, set the switch at "ON" to place the Automatic Noise Limiter circuit in operation.

### 3-7. VOLUME CONTROL.

This control is used to regulate receiver volume. Clockwise rotation increases volume; counterclockwise rotation decreases volume.

### 3-8. PITCH CONTROL.

This control is used to vary the pitch of code signals, and should be set for the tone most pleasing to the operator. For this control to have any effect, the AM-CW switch must be set at "CW".

### 3-9. TONE CONTROL.

The TONE control is a combination receiver ON-OFF switch and 3-position TONE control. In the "PWR OFF" position, the receiver is inoperative. To turn the receiver on, simply rotate the control to any of its three remaining positions. For AM reception, set the control for the desired tonal quality. For CW reception, set the control at "LOW".

### 3-10. TUNING AND BANDSPREAD CONTROLS.

The TUNING and BANDSPREAD controls are used in conjunction with one another to tune in the desired signal. Wide tuning is performed with the TUNING control and fine tuning with the BANDSPREAD control.

## A. MAIN TUNING DIAL.

The main tuning or left-hand dial is operated by the TUNING control. This dial has four calibrated scales, one for each of the four frequency bands covered by the receiver. It also contains a 20 division logging scale for accurately logging and relocating stations of special interest. The main tuning dial should be set for the desired station frequency after the BANDSPREAD control has been set fully clockwise (minimum bandspread tuning capacity).

### IMPORTANT

The receiver frequency readings or calibration on the main tuning dial will be correct only if the BANDSPREAD control has been set fully clockwise. If it is set at any other setting, the additional bandspread capacity added to the main tuning capacity will throw off the main tuning dial calibration, because the receiver has been calibrated with the bandspread tuning capacitor set at minimum.

The dial settings for the 80, 40, 20, 15, and 10 meter bands are indicated on the main tuning dial by white dots. When tuning with the bandspread dial, the main tuning dial must be set at the dot corresponding to the desired band. The 160 meter band is indicated on the dial by three short double-weight lines.

## B. BANDSPREAD DIAL.

The bandspread or right-hand dial is operated by the BANDSPREAD control. This dial contains five scales calibrated for the 80, 40, 20, 15, and 10 meter bands. These five scales are calibrated to read receiver frequency directly when the main tuning dial has been set to the index dot of the desired band. For convenience in tuning, the AM phone bands are indicated on the bandspread dial by double-weight lines.

The bandspread dial may also be utilized as a fine tuning adjustment over any portion of the receiver tuning range. Two methods of fine tuning are described below.

- (1). The first method of fine tuning is used when it is desired to tune in a single signal with precision accuracy. First the BANDSPREAD control is set a few degrees from its full clockwise position, then the desired signal is located with the TUNING control, and finally the signal is accurately tuned in by "rocking" the BANDSPREAD control (turning it slightly to the left and right) until the signal is loudest and clearest.
- (2). The second method of fine tuning is used when it is desired to tune through a group of signals. With the BANDSPREAD control set fully clockwise, adjust the TUNING control to tune in the highest-frequency signal in the group. The other

signals can then be heard by slowly turning the BANDSPREAD control in a counterclockwise direction.

### 3-11. STANDBY-RECEIVE SWITCH.

This switch, normally set at "REC", permits you to silence the receiver without turning it off. To silence the receiver, set the switch at "STANDBY". In this position, the RF and IF stages are cut off, but the tube heaters remain at operating temperature for instant use. To resume reception at any time, simply return the switch to the "REC" position.

### 3-12. SERVICE OR OPERATION QUESTIONS.

For any further information regarding operation or servicing of your receiver, contact your Hallcrafters dealer. The Hallcrafters Co. maintains an extensive system of authorized service centers where any required service will be performed promptly and efficiently at a nominal charge. All Hallcrafters Authorized Service Centers display the sign shown to the right. For the location of the one nearest you, consult your dealer or telephone directory.



Do not make any service shipments to the factory unless instructed to do so by letter. The Hallcrafters Company will not accept the responsibility for any unauthorized shipments.

The Hallcrafters Co. reserves the privilege of making revisions in current production of equipment and assumes no obligation to incorporate these revisions in earlier models.

## SECTION IV SERVICE DATA

### 4-1. TECHNICAL SPECIFICATIONS.

TUBES ..... Eight including rectifier  
SPEAKER ..... 5 inch PM; 3.2 ohm voice coil  
HEADPHONE OUTPUT ..... Low impedance  
(See Par. 2-5)  
ANTENNA INPUT ..... For single wire or 52-600 ohm  
balanced or unbalanced line.  
POWER SOURCE ..... 105-125 volts, 50-60 cycles AC  
POWER CONSUMPTION ..... 75 watts  
RECEPTION ..... AM and CW  
INTERMEDIATE FREQUENCY ..... 455 KC  
AUDIO OUTPUT IMPEDANCE ..... Matches 3.2 ohms

DIMENSIONS.. 18 3/4" wide x 10 1/4" deep x 8" high  
WEIGHT, Net ..... 28 lbs., 4 oz.  
WEIGHT, Shipping ..... 32 lbs.

#### FREQUENCY COVERAGE

Band	Frequency Range	Calibrated Band Spread
1	.538 - 1.6 MC	-
2	1.55 - 4.6 MC	80M
3	4.6 - 13.0 MC	40M
4	12.0 - 34.0 MC	20, 15, and 10M

### 4-2. TUBE AND DIAL LAMP REPLACEMENT.

To gain access to the tubes and dial lamps, see

"CHASSIS REMOVAL". The tube locations, as well as their functions, are shown in Fig. 6.

### 4-3. CHASSIS REMOVAL.

The chassis and front panel assembly are removable from the cabinet as a unit by removing the three screws at each side of the front panel and the five screws on the underside of the cabinet. When removing the chassis from the cabinet, care should be taken not to damage or disturb any of the variable adjustments.

### 4-4. DIAL CORD RESTRINGING.

To restring the TUNING or BANDSPREAD dials, first remove the chassis from the cabinet. See "CHASSIS REMOVAL". Remove the front panel from the cabinet by removing the control knobs, the four toggle switch and PHONES jack decorative nuts, and the two screws at the bottom of the front panel. Then remove the main tuning dial to gain access to the drive pulleys. For stringing details, refer to Fig. 5. Note that stringing is done with the TUNING and BANDSPREAD gangs fully meshed. After stringing is completed, cut off the excess dial cord and apply a drop of quick drying cement to the knots.

With the TUNING and BANDSPREAD gangs fully meshed, replace the dial so that the index marks at the low frequency end of the dial are in line with the hairline on the dial window.




Figure 5. Dial Card Stringing Diagram.

## SECTION V ALIGNMENT

### 5-1. GENERAL.

This receiver has been carefully aligned at the factory by specially trained personnel using precision equipment. Alignment of the receiver should not be attempted until all other possible causes of faulty operation have been investigated. Alignment should not be required unless the receiver has been tampered with or component parts have been replaced in the RF or IF stages. Alignment should only be made by persons familiar with communications receivers and experienced in their alignment. Refer to Figs. 6 and 7 for location of all alignment adjustments.

### 5-2. EQUIPMENT REQUIRED.

1. Signal generator covering 455 KC to 28 MC.
2. Output meter (or AC scale of VTVM). Connect meter from 3,2 ohm speaker terminal to ground.

3. Non-metallic alignment tool.
4. Standard RTMA dummy antenna shown in Fig. 8.
5. 0.02 mfd. capacitor.

### 5-3. INITIAL CONTROL SETTINGS.

BAND SELECTOR ..... As indicated in chart.  
 SENSITIVITY AND VOLUME ..... Maximum.  
 NOISE LIMITER AND AVC ..... OFF  
 STANDBY-RECEIVE ..... REC  
 TONE ..... HIGH  
 AM-CW ..... AM  
 TUNING ..... Fully clockwise  
 BANDSPREAD ..... Extreme right position.





Figure 6. Top View Chassis Tube Locations and Alignment Points.





## SERVICE PARTS LIST

Part Symbol	Description	Manufacturer Part Number	Schematic Symbol	Description	Manufacturer Part Number	Schematic Symbol	Description	Manufacturer Part Number
CAPACITORS			RESISTORS (CONT)			TUBES AND DIAL LAMPS		
C1, 12	4-80 mmf.; Mica Trimmer	944-100395	R20	500K ohm, variable;	025-201748	V1	68G7; RF Amplifier	090-901181
C2, 13	3-30 mmf.; Mica Trimmer	944-100396	R21	VOLUME control	453-253151	V2	68A7; Converter	090-901180
C3, 14	1.5-15 mmf.; Mica Trimmer	944-100397	R22, 60	250K ohm, 20%	453-253274	V3, 4	68B7; 1st and 2nd IF Amplifiers	090-901223
C4, 15, 12	2-20 mmf.; Mica Trimmer	944-100618	R23, 24	470K ohm, 20%	453-253274	V5	68C7; BFO and Audio Amplifier	090-900974
C5A, B, C	Variable Capacitor, 3 section, Bandspread Tuning (gutter included)	948-300448	R24	500 ohm, 1 Watt	453-253261	V6	68G7; Audio Output Amplifier	090-900856
C7A, B, C	Variable Capacitor, 3 section, Main Tuning (gutter included)	948-100448	R25, 10	1.5K ohm, 1/2 Watt, W.W.	453-253153	V7	68G7; Audio Output Amplifier	090-900847
C8, 32, 35	50, 60, .05 mfd., +20, -10%, 500V.; Tubular	499-012560	R26	15 megohm, 20%	453-253156	LMI	AVC Lamp, Dial; Type 47	039-130904
C9, 28	.02 mfd., +20, -10%, 500V.; Tubular	499-032565	R27	27 ohm	453-252250	LMI, 2	TEMP. Dial; Type 44	039-130903
C10	22 mmf., N750, Cer. Tubular	491-107220-95	R28	160K ohm	453-252254	LMI	Lamp, Dial; Type 47	039-130904
C11	10 mfd., Neutralizing	347-200160-34	R29	6.8 ohm, 1 Watt	453-252260	KNOBS		
C16	390 mmf.; 10%, 500V.; Mica	470-213391	R30	250 ohm	453-252331	Knob, VOLUME	015-381268	
C17, 53	0.01 mfd., +20, -10%, 500V.; Tubular	499-032162	R37	330K ohm	453-252334	Knob, BAND SELECTOR and PTCH CONTROL	015-381290	
C18	150 mmf., 5%, 500V.; Mica	470-213391	R70	47 ohm, 1 Watt	453-252470	Knob, SENSITIVITY and PWR.-OFF TONE	015-381258	
C19	4-70 mmf.; Mica Trimmer	944-100418	*All resistors are 10%, 1/2 watt, carbon type unless otherwise specified.					
C20, 21	2-30 mmf.; Mica Trimmer	944-100418	**COILS AND TRANSFORMERS					
C23	3300 mmf., 5%, 500V.; Mica	470-222332	L1	Coil, Antenna (Band 4); Inc. C1	051-201907	MISCELLANEOUS PARTS		
C24	1500 mmf., 5%, 500V.; Mica	470-222332	L2	Coil, Antenna (Band 3); Inc. C2	051-201908	Cabinet Weld Assy.	066-402482	
C25	320-520 mmf.; Mica Powder	444-100394	L3	Coil, Antenna (Bands 1 and 2); Inc. C3	051-201909	Clamp, Window Retainer	076-100683	
C27A, B, C	30-10-10 mfd., .450V.; Electrolytic	045-100062	L4	Coil, Mixer (Band 4); Inc. C1	051-201908	Dial Cord	038-130949	
C29, 33	120 mmf., 10%, 500V.; .01 mfd., +20, -10%; 500V.; Tubular	499-012203	L5	Coil, Mixer (Band 3); Inc. C1	051-201908	Dial, MAIN TUNING	063-400713	
C31, 43	.01 mfd., +20, -10%; 500V.; Tubular	499-012203	L6	Coil, Oscillator (Band 4); Inc. C1	051-201900	Dial Plate Weld Assy.	053-354152	
C38	3 mmf.; Wire Gimmick	-----	L7	Coil, Oscillator (Band 3); Inc. C2	051-201899	Dial Window, BANDSPREAD	083-400717	
C39	.02 mfd., +20, -10%, 500V.; Tubular	499-021304	L8	Coil, Oscillator (Band 2); Inc. C2	051-201898	Dial Window, BANDSPREAD	083-400717	
C41, 45	47 mmf., 20%, 500V.; Mica	470-234470	L9	Coil, Oscillator (Band 1); Inc. C2	051-201897	Front Panel Weld Assy.	016-100907	
C46, 48, 52, 63	.02 mfd., +20, -10%, 500V.; Tubular	499-032260	L10	Coil, Oscillator (Band 1); Inc. C2	051-201897	Line Cord Lock, Male	076-100397-01	
C47	.0022 mfd., +20, -10%, 1000V.; Tubular	499-042232	L11	Coil, DFO	054-200681	Line Cord Lock, Female	076-100397-02	
C54	470 mmf., 20%, 500V.; Mica	470-212471	T1, 2	Transformer, 1st and 2nd IF	050-306243	Pincher, BANDSPREAD	083-290448	
C56	.01 mfd., 20%, 1400V.; Cer. Disc	547-001309	T3	Transformer, IF; detector stage	050-306242	Post, Drive (MAIN TUNING and BANDSPREAD)	074-202274	
C57	.001 mfd., 20%, 500V.; Mica	470-314102	T4	Transformer, Audio Output	055-000449	Spring	076-100412	
C61	.25 mfd., +20, -10%, 200V.; Tubular	499-012264	T5	Transformer, Power	055-100229	Terminal Board, Antenna Trim Srg	086-100322	
C64	10 mfd., 25V.; Electrolytic	945-100121	*Coils L1 through L10 are supplied complete with trimmer capacitor. Trimmers are also available separately. See "Capacitors".					
*RESISTORS			SWITCHES					
R1, 81	1 megohm, 20%	451-253105	S1A	Wafer Switch, Antenna	965-200389	TESTERS		
R2, 82	120 ohm, 20%	451-253121	S1B	Wafer Switch, Mixer	965-200393	Tester, Speaker	007-400740	
R3, 83	10K ohm, variable; SENSITIVITY control	451-253150	S1C	Wafer Switch, Oscillator	965-200444	Trimmer Board, Antenna Trim Srg	086-100322	
R4, 31	22 ohm, 20%	451-253220	S2, 3, 5, 6	Switch, SPST Toggle	964-100128	Tester, Speaker, 3.2 ohm	007-400740	
R5, 32	50K ohm, 1 Watt	451-253239	STANDARD REC. NOISE LIMITER, AVC and AM-CW					
R6, 36	6.8K ohm, 1 Watt	451-253262	S4	Switch, Rotary; PWT/ OFF/TONE	960-203115	TESTERS		
R7	22K ohm	451-253223	Shaft, Bandswitch and Index, Play					
R8	10K ohm, 3 Watt	451-253210	960-200382					
R9, 11	470 ohm	451-253471	JACKS, PLUGS, AND SOCKETS					
R10	12K ohm, 4 Watt W.W.	924-101062	J1	Jack, PHONE	026-100002	TESTERS		
R12, 69	3.3 megohm, 20%	451-253225	PL1	Line Cord and Plug Assy. Socket, Dial Lamp Assy.	087-100078	TESTERS		
R14	47K ohm, 20%	451-253473	Socket, Tub; Octal (V1 thru V10)					
R15, 29, 58	10K ohm, 20%	451-253214	086-100476					
R16, 65	100K ohm, 20%	451-253210	086-100250					



## NOTES




Figure 10. Model S-108 Schematic Diagram.

## Warranty

"The Hallicrafters Company warrants each new radio product manufactured by it to be free from defective material and workmanship and agrees to remedy any such defect or to furnish a new part in exchange for any part of any unit of its manufacture which under normal installation, use and service discloses such defect, provided the unit is delivered by the owner to our authorized radio dealer, wholesaler, from whom purchased, or, authorized service center, intact, for examination, with all transportation charges prepaid within ninety days from the date of sale to original purchaser and provided that such examination discloses in our judgment that it is thus defective.

This warranty does not extend to any of our radio products which have been subjected to misuse, neglect, accident, incorrect wiring not our own, improper installation, or to use in violation of instructions furnished by us, nor extend to units which have been repaired or altered outside of our factory or authorized service center, nor to cases where the serial number thereof has been removed, defaced or changed, nor to accessories used therewith not of our own manufacture.

Any part of a unit approved for remedy or exchange hereunder will be remedied or exchanged by the authorized radio dealer or wholesaler without charge to the owner.

This warranty is in lieu of all other warranties expressed or implied and no representative or person is authorized to assume for us any other liability in connection with the sale of our radio products."

Form No. 943622

*the Hallicrafters co.*